





# MetaModule MetaAIO Expander

## Installation:

1. Power off your system.
2. Connect one end of the included 10-pin cable to the header labeled “Audio Expander” on the MetaModule, and the other end to the 10-pin header on the MetaAIO expander.
3. Make sure the red stripe is to the **right** on both ends of the cable.
4. Connect the included 16-pin power cable to Eurorack power. Make sure the red stripe is facing **down**.



5. Power on your case. To check if the connection was successful, navigate to Settings > Info. At the bottom of the screen under the word “EXPANDERS” it should read “Audio/CV Expander connected.” Make sure to use firmware v1.6.7 or later.




(continued on other side)

(continued from other side)

**Usage:**


1. Navigate to a jack on MetaModule.



2. Click “New panel cable”



3. Select your desired input or output jack with the prefix “Exp.”



Questions? Need Help? <https://metamodule.info>