


# Pods


## Compact Eurorack Enclosures from 4ms Company

Usage Guide 5.1 – June 18, 2025




4ms Pods are low-cost, portable, compact enclosures that turn Eurorack modules into table-top instruments. Pods come with an integrated power supply which allows you to daisy-chain multiple units in different configurations using only a single power brick.

### Overview



**Available in 20HP, 26HP, 32HP, 34HP, 40HP, 48HP, 60HP, 64HP, 104HP**

	+12V	-12V	+5V	Headers
Pod20/26/32	0.7A	0.28A	1.0A	2
Pod34X/40X/48X	1.4A	0.67A	1.0A	4
Pod60/64X	1.4A	0.67A	1.0A	6
Pod104X	2.0A	1.4A	1.5A	13



## Installing a module

---

Congratulations on your purchase of a Pod! It's easy to install a standard Eurorack module in a Pod:

- (1) Unplug barrel cables and power brick cables from the Pod.
- (2) Attach your module's power ribbon cable to a 16-pin power header on the Pod.  
*The Pod power header is keyed so that the cable cannot be inserted upside-down. The red stripe should be down, and should connect to the -12V on the module.*
- (3) Connect the other end of the ribbon cable to your Eurorack module (unless it's already be attached, of course!)
- (4) Place the module into the Pod so that all screw holes on the module's faceplate line up with the screw holes on the Pod.
- (5) Use M3 screws (included with Pod) to secure the module's faceplate to the Pod.
- (6) Repeat steps 2-5 to install more modules. If you need to install more modules than there are power headers, you can use a Multi Power Cable.
- (7) Power on the Pod by plugging a power brick into either one of the jacks on the back of the Pod.  
*Or, if you already have another Pod that's receiving power, you can daisy-chain the new Pod using a barrel cable.*
- (8) Optional: you may attach the included adhesive rubber feet to the bottom of your Pod. To use Pods on a pedalboard, you may attach Velcro or hook-and-loop fastener instead (not included)

## Power

---

Pods have an integrated power supply with standard Eurorack power headers. The Pod20, Pod26 and Pod32 have two headers; the Pod34X, Pod40X and Pod48X have four headers; the Pod60 and Pod64X have six headers, and the Pod104X has 13 headers. All Pods work with all modules that use 10 and/or 16-pin power cables.

### Power Bricks

To supply power to a single Pod, plug a Power Brick (sold separately) to either one of the jacks on the back of the Pod. Wherever Pods are sold, you can purchase a Power Brick that's compatible with the Pods. You also can use the Power Brick sold for use with the Row Power system (90W Brick). Or you can use your own power brick as long as it meets these specifications:

- *Voltage*: 15VDC to 24VDC
- *Style*: 2.1mm positive tip barrel plug (5.5mm outer diameter)
- *Wattage or amperage*: No particular specification is required. Virtually every modern power brick will be able to power six or more daisy-chained Pods. We recommend at least 15W of power (most bricks are 30W-100W)

### **Daisy-chaining**

Pods are meant to be daisy-chained. When you plug a Power Brick into one of the jacks on the back of a Pod, the other jack can be used to power an additional Pod. Simply connect a Barrel Cable from one Pod to the next. You can continue to daisy-chain Pods to make long chains! With the 45W Power Brick sold for use with Pods, eight or more Pods can be daisy-chained (depending on the total power consumption of all the modules).

### **Unpowered Pods**

Pods are usually sold with a power supply, but some pods can also be sold Unpowered. An Unpowered Pod is essentially an empty metal box perfectly sized for Eurorack modules.

If you purchased an Unpowered Pod, you'll see there are no power headers or jacks on the back. You will need to provide your own power supply for your modules. If you have a Row Power module, it can be installed on the top of the Pod as a normal module. Additionally, there are two holes on the back of the Unpowered Pod which are plugged with a plastic insert: you can use these holes to mount a jack which connects to your own DIY power supply.

### **Tips**

---

- Pods use M3 screws (which are included). You may use any other M3 screw, such as Befaco Knurlies, but do not use screws with other thread sizes to avoid permanently damaging the threads of the Pod.
- The Pod40X and Pod48X series have 1.97" (50mm) of depth on the inside; the Pod34X, 64X, and 104X have 2.16" (55mm); and the thin Pods (Pod20/26/32/60) have 1.34" (34mm) of depth on the inside. The depth of your module, including the power header, must be less than or equal to this. Due to manufacturing variances and the flexibility of the materials, this dimension may vary +/-5%.
- Exceeding the maximum power draw for a Pod may cause modules to function poorly (or not at all). It's possible that exceeding the maximum ratings may damage your modules (this is true for any power supply).

## Specifications

### Powered Pod Includes:

- Pod, black anodized aluminum
- Built-in power supply with two Eurorack power headers
- M3 x 8mm screws (10 for Pod48X and smaller; 20 for Pod60 and Pod64)
- Adhesive rubber feet (4)
- Does not include barrel cable or power brick

Power Specifications	+12V	-12V	+5V	Headers
Pod20, Pod26, Pod32	0.7A	0.28A	1.0A	2
Pod34X, Pod40X, Pod48X	1.4A	0.67A	1.0A	4
Pod60, Pod64X	1.4A	0.67A	1.0A	6
Pod104X	2.0A	1.4A	1.5A	13

### Earlier versions of powered Pods:

- Pod20/26/32's with power PCB 1.0 have a +5V maximum of 0.2A
- Pod40X/48X with power PCB 1.0 have a +5V maximum of 0.5A
- Pod60's with power PCB 1.0 have 4 power headers and a +5V maximum of 0.5A
- Early Pod60s with two separate power PCBs have 0.4A max of +5V, and 0.56A max of -12V, and the power draw of any single module must not exceed half the maximum ratings.

### Power input:

- Two barrel jacks for daisy-chaining, 2.1mm positive tip.
- Voltage: 15V - 24VDC maximum

### Exterior dimensions:

- Width:
  - Pod20: 106.1mm (4.18")
  - Pod26: 136.6mm (5.38")
  - Pod32: 167.1mm (6.58")
  - Pod34X: 177.3mm (6.98")
  - Pod40X: 207.7mm (8.18")
  - Pod48X: 248.3mm (9.78")
  - Pod60: 309.3mm (12.18")
  - Pod64X: 329.7mm (12.98")
  - Pod104X: 534mm (21")
- Height: 159.5mm (6.28")
- Depth:
  - Pod20/26/32/60: 36mm (1.42")
  - Pod40X/48X: 52mm (2.04")
  - Pod34X/64X/104X: 57mm (2.24")

### Interior dimensions:

- Module depth:
  - Pod20/26/32/60: 34mm (1.34")
  - Pod40X/48X: 50mm (1.95")
  - Pod34X/64X/104X: 55mm (2.16")
- Module width:
  - HP size \* 5.08mm (0.2")
- Weight (powered):
  - Pod20: 0.17 kg (6 oz)
  - Pod26: 0.21 kg (7 oz)
  - Pod32: 0.23 kg (8 oz)
  - Pod34X: 0.3 kg (10 oz)
  - Pod40X: 0.31 kg (11 oz)
  - Pod48X: 0.35 kg (12 oz)
  - Pod60: 0.40 kg (14 oz)
  - Pod64X: 0.5 kg (17 oz)
  - Pod104X: 1.02kg (36oz)

